


Test Pen



Instructions

The voltage indicator is suitable for testing AC voltages from 100V up to 500 V against earth. Touch the metal tip on top of the insulated part of the test pen to operate it. Light up indicates current flow and no light indicates dead current.
 Note: Failure to light up does not indicate with certainty that no voltage is present.



Stock code

| No. | Description |
|--------------|-------------------------------------|
| HWTP3552.CCM | CCM M10 3552 TEST PEN (SHORT 145MM) |